

Formula for Calculation of Elongation

(a) Bolt Stress/30,000,000 X Effective length

Example

2" stud preload of 50,000 psi with 8" effective length

$50,000/30,000,000=0.00166666$

Time 8= 0.0133 elongation.