

Well Head Services Inc

F:Load Loss Formula

F=1.15+2/R\*R, where R is the Grip Length/Stud Diameter

$$F = 1.15 + \frac{2}{R} * R$$